



Note; the plastic on the cowl is a very soft material. If you apply pressure on it with a tool, it will turn white. Do not apply pressure to the material with your cutters until you are certain that you are in the correct position.

7. Remove the knockouts in your cowl. Use side cutters to cut the tabs at the yellow arrow and not the red arrow. Cut all 6 tabs. Once you have the center portion removed, use a set of end nippers from the rear of the cowl as shown in the lower right photo to remove any of the tab that remains on the cowl.

8. Install the edge trim. We include a rubber edge trim to properly finish off the edge. First, use your side cutters to create a clean 90 degree edge on one end of the trim. Open the trim and press it into place starting at the top (the top is the least visible portion once the cowl is reinstalled). Work your way around the hole pressing the trim in place. The material does not require any glues or adhesive. Once you have installed the trim all the way around the edge, you will need to use your side cutters again to create the other end of the trim. We suggest that you cut it slightly longer than you think it will need to be and press the 2 ends against each other and then finish pressing the trim into place. You can always remove one end and trim it slightly shorter. Take your time as the trim will really finish out your installation. (R)

9. Mount the light to the bike using the bolt you removed in step 3. Position the bolt in the center of the slot as shown in the insert pic with yellow arrow. Use your wrench to tighten the bolt so that the light is held in place. We will need to adjust the side to side position of the light behind the hole in the cowl, so don't overtighten the bolt. (R)

10. Place the cowl on the bike by inserting the 2 tabs on the outside into their slots. Then line up the holes for bolts. Note the position of the light in reference to the cowl cutout. This light needs to be moved towards the outside. Loosen the bolt from the previous step and slide the bracket as needed and retighten bolt. Check alignment until the optimum position is achieved. (R)

11. Install the 10/32 screw shown at the bottom yellow arrow. If the brackets are not touching, adjust "L" bracket. Position the screws that attach the light in the center of the slots as shown in the insert pic (green arrows) on the right side below. Once centered, tighten ONLY the bottom screw. Now place the cowl back on the bike and note the up and down orientation of the light. Move the light as needed at the red arrows. Once adjustment is done, tighten all hardware including main bolt. (R)

